

Honeywell
Honeywell Sensing and Productivity Solutions

Honeywell

## AML23GBB2AA05

Inombolo yendawo:	AML23GBB2AA05
Umkhqizi / Umshicileli:	Honeywell Sensing and Productivity Solutions
Ingcaciso yeMveliso	SWITCH TOGGLE SPDT 3A 125V
Maxwebhu:	<a href="#">AML23GBB2AA05.pdf</a>
RoHS Imeko	Ukukhokela mahala / RoHS Ukuthobela
Umkhumbi	ehong Kong
Indlela yokuthunyelwa	DHL/Fedex/TNT/UPS/EMS

ISICELO

SESIKATSHULWA

Umfanekiso ungabonakaliswa. Bona iinkcukacha zeenkukacha zeemveliso.

### Iinkcukacha zeAML23GBB2AA05

INOMBOLO YENDAWO	AML23GBB2AA05
UMENZI	Honeywell Sensing and Productivity Solutions
INKCAZO	SWITCH TOGGLE SPDT 3A 125V
ISIMO SOBUME BENKOKELI / ISIMO SEROHS	Ukukhokela mahala / RoHS Ukuthobela
ISHITI YEDATHA	<a href="#">AML23GBB2AA05.pdf</a>
I-VOLTAGE RATING - DC	24V
I-VOLTAGE RATING - AC	125V
STYLE TERMINATION	Solder, Quick Connect - 0.110" (2.8mm)
SHINTSHA UMSEBENZI	Mom-Off-Mom
UCHUNGECHUNGE	AML23
I-PANEL CUTOUT UBUKHULU	Rectangular - 28.98mm x 19.05mm
PACKAGING	Bulk
UKUSHISA OKUSEBENZAYO	-
UHLOBO LOKUPHAKAMISA	Panel Mount, Snap-In
INQANABA LOKUSONDEZA UBUNINZI (MSL)	1 (Unlimited)
ISIMO SOBUME BENKOKELI / ISIMO SEROHS	Lead free / RoHS Compliant
UKUKHUSELA I-INGRESS	-
UKUKHANYISA IVOTTAGE (IGAMA LOMNTU)	6 VAC
UHLOBO LOKUKHANYISA, UMBALA	Incandescent
UKUKHANYA	Illuminated
IIMBONAKALO	-
UBOMI BOMBANE	25,000 Cycles
INKCAZO ECACILEYO	Toggle Switch SPDT Panel Mount, Snap-In
ISILINGANISO SAMANJE	3A (AC), 2A (DC)
ISIPHALUKA	SPDT
BUSHING THREAD	-
UHLOBO LWE-ACTUATOR	Paddle
IZINTO ZOKUKHUPHA	-
UBUDE BOKUGUQULA	-

### Amanqaku afanayo

Honeywell Sensing and Productivity Solutions AML23GBB2AA05	Umhambisi we-AML23GBB2AA05	Umboneleli we-AML23GBB2AA05
Ixabiso le-AML23GBB2AA05	Imifanekiso ye-AML23GBB2AA05	Umfanekiso we-AML23GBB2AA05
Idatha ye-AML23GBB2AA05 yePD	I-AML23GBB2AA05 Khuphela iDatasheet	Idatha ye-AML23GBB2AA05
Ivenkile ye-AML23GBB2AA05	Thenga iAML23GBB2AA05	Thenga iHoneywell Sensing and Productivity Solutions AML23GBB2AA05
Honeywell Sensing and Productivity Solutions AML23GBB2AA05	Umboneleli we-Honeywell Sensing and Productivity Solutions	Umhambisi we-Honeywell Sensing and Productivity Solutions
Honeywell Sensing and Productivity Solutions AML23GBB2AA05	HONEYWELL AML23GBB2AA05	Honeywell Sensing and Control EMEA AML23GBB2AA05
Honeywell Sensing and Productivity Solutions T&M AML23GBB2AA05		

### Iimveliso ezihambelanayo

<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBC2AA04</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBA3AA05</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBC2AA01</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBC2CA02</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBB3AA04</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBB2CA05</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBA3CA04</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBC2CA01</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBB2AA01</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBB2AA04</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE SPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBA3CA05</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <span style="font-weight: bold; color: red; font-size: 24px;">Honeywell</span> <div> <p style="margin: 0;"><b>AML23GBA3CA06</b></p> <p style="margin: 0; font-size: 10px;">Abavelisi: Honeywell Sensing and Productivity Solutions</p> <p style="margin: 0; font-size: 10px;">Inkcazo: SWITCH TOGGLE DPDT 3A 125V</p> <p style="margin: 0; font-size: 10px;">Ikhona evenkileni: Out stock</p> <div style="background-color: #ccc; padding: 5px; text-align: center; width: fit-content; margin: 5px auto;">RFQ</div> </div> </div>