

CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S

Inombolo yendawo:	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Umkhqizi / Umshicileli:	Schurter
Ingcaciso yeMveliso	SWITCH PUSHBUTTON SPST 100MA 42V
Maxwebhu:	PDF CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S.pdf
RoHS Imeko	Ukukhokela mahala / RoHS Ukuthobela
Umkhumbi	ehong Kong
Indlela yokuthunyelwa	DHL/Fedex/TNT/UPS/EMS

ISICELO
SESIKATSHULWA

Umfanekiso ungunonakaliswa. Bona iinkcukacha zeenkukacha zeemveliso.

Iinkcukacha zeCPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S

INOMBOLO YENDAWO	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
UMENZI	Schurter
INKCAZO	SWITCH PUSHBUTTON SPST 100MA 42V
ISIMO SOBUME BENKOKELI / ISIMO SEROHS	Ukukhokela mahala / RoHS Ukuthobela
ISHITI YEDATHA	PDF CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S.pdf
I-VOLTAGE RATING - DC	60V
I-VOLTAGE RATING - AC	42V
UHLOBO	Capacitive, Illuminated
STYLE TERMINATION	Wire Leads
SHINTSHA UMSEBENZI	Off-On
UCHUNGECHUNGE	CPS
I-PANEL CUTOOUT UBUKHULU	Circular - 19.10mm Dia
PACKAGING	Bulk
UKUSHISA OKUSEBENZAYO	-40°C ~ 60°C
UHLOBO LOKUPHAKAMISA	Panel Mount, Front
INQANABA LOKUSONDEZA UBUNINZI (MSL)	1 (Unlimited)
LIFE MECHANICAL	-
ISIMO SOBUME BENKOKELI / ISIMO SEROHS	Lead free / RoHS Compliant
UKUKHUSELA I-INGRESS	IP67 - Dust Tight, Waterproof
UKUKHANYISA IVOTTAGE (IGAMA LOMNTU)	5 ~ 28 VDC
UHLOBO LOKUKHANYISA, UMBALA	LED, White/Cyan
IIMBONAKALO	DOWN Symbol
UBOMI BOMBANE	-
INKCAZO ECACILEYO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
ISILINGANISO SAMANJE	100mA (AC/DC)
UMBALA - I-ACTUATOR / CAP	Silver
ISIPHALUKA	SPST
UHLOBO LWE-ACTUATOR	Round, Button, Flush

Amanqaku afanayo

Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Umhambisi we-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Umboneleli we-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Ixabiso le-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Imifanekiso ye-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Umfanekiso we-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Idatha ye-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S yePD	I-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S Khuphela iDdatasheet	Idatha ye-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Ivenkile ye-CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Thenga iCPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Thenga iSchurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Umboneleli we-Schurter	Umhambisi we-Schurter
Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	

Iimveliso ezihambelanayo

<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1074-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1073-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1066-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1069-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1065-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1071-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1070-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1067-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1063-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1062-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1072-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1064-S Abavelisi: Schurter Inkcazo: SWITCH PUSHBUTTON SPST 100MA 42V Ikhona evenkileni: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>